FELCOM18 Operator's Guide The purpose of this guide is to provide the basic operation for this equipment. For more detailed information, see the Operator's Manual.

All brand and product names are trademarks, registered trademarks or service marks of their respective holders.

LOGIN, LOGOUT

English

Login

Confirm that the terminal unit is idle then do the following:

- 1. Confirm that [SYNC (NCS)] appears at the bottom of the screen.
- 2. Press the F7 key to display the [Options] menu.

Options
1. Position
2. Login
Logout
4. Abort
Select NCS
6. Ocean Region
7. LES Information
8. Test
9. Maintenance

3. Press the 2 key to display the [Login] screen.



4. [Yes] is selected in the [Start] window; press the **Enter** key to start the login process.

When login is completed, the message "Successful Login" appears. Press the **Esc** key to go to the standby display.

Logout

- 1. Press the **F7** and **3** keys to display the [Logout] screen.
- [Yes] is selected in the [Start] window; press the Enter key to start the logout process.

When logout is completed, the message "Successful Logout." appears and the [Current State] indication changes from [LOGOUT] to [IDLE]. Then, turn off the FELCOM.

HOW TO SEND A MESSAGE TO A STA-TION SAVED TO THE STATION LIST

- Prepare message on the screen.
 For e-mail, set [Text Mode] in the [Editor Setup] menu to [Ascii].
- 2. Press the F3 key to display the [Transmit] menu.



3. Press the 1 key to display the [Transmit Message] menu.

	——Transmit Messag	e	
Priority	Normal		
Message File		Size	24
Station Name			
Destination Type	TELEX/MES		
Prefix Code			
Country/Ocean Co	ode 82		
Destination	65-2111		
Modem Type			
Address			
Subject			
Attach File			
LES ID	303 (KDDI)		
Option	ON		
Confirmation	00:00		
Send Delay	Immediate		
Delivery Delay	IA5		
Code			
[TRANSMIT]			

4. Select [Station Name] then press the **Enter** key to open the Station List.

Grou	p Station Name	— Зтапо Туре	Code	ID / Address
01 02 03 04 05 06 07	FURUNO FRNINMBTSTS Seagull whale	TELEX/ TELEX/ E-Mail E-Mail	583 Seagu	321 343199999 Il@furuno.co.jp @furuno.co.jp
1 *	ect SPACE: Select trl+G: Group, Ctrl+N			CE: Cancel Mark INS: Edit trl+T: Type)

- Choose a station then press the Enter key. To select multiple stations (simultaneous transmission), select a station and then press the Spacebar.
- 6. For e-mail do the following. For other types, go to step 7.1) Select [Subject] then press the **Enter** key.
 - 2) Type subject then press the Enter key.
 - 3) To attach a file, select [Attach File] then press the **Enter** key.
 - 4) Press the Enter key to open the file list.
 - 5) Select a file then press the Enter key.
 - 6) Press the **Esc** key to close the window. Go to step 7.
- 7. Select [LES ID] then press the **Enter** key to open the LES setting window.

Name	LES ID	Remarks
Vizada 201	201	USA
Stratos Global	202	CANADA
KDDI	203	JAPAN
Vizada (NOR)	204	NORWAY
Korea Telecom	208	SOUTH KOREA

- 8. Select an LES then press the Enter key
- 9. Select [Confirmation] then press the Enter key.
- 10. To request notification of delivery from the LES, select [ON]. If not necessary select [OFF]. Press the **Enter** key.
- Select [Send Delay] then press the Enter key. To send a message after a certain delay, enter a time up to 23 hours 59 minutes. Press the Enter key.

- 12. Select [Delivery Delay] then press the Enter key. Select [Immediate] or [Deferred] then press the Enter key.
- 13. Select [Code] then press the Enter key.
- 14. Select [IA5] then press the Enter key.
- 15. Put the cursor on [TRANSMIT] then press the Enter key to show the [Start] window.
- 16. Press the Enter key to send the message to the message queue.
- 17. Long-press the **Esc** key to return to the standby display.

If the message was sent successfully, "Successful Sending message" appears and the TX message is printed (if [Confirmation] is OFF).

How to cancel transmission on a message awaiting transmission

Press the F3 and 2 keys to show the [Cancel] screen.

No.	Message File		Cancel — LES	Priority	Send Status
01	S11111.001	INET	Vizada 101	Normal	Sending

Select the message to cancel then press the Enter key. Press the Enter key again to cancel the message.

HOW TO SEND THE DISTRESS ALERT

When a life-endangering situation arises on your vessel, send the distress alert as shown below.

- 1. If you have time to specify the nature of distress do steps 1) to 15) below. If not, go to step 2.
 - 1) Press the F9 key to display the [Distress Alert Setup] screen.



- 2) [LES ID] is selected; press the Enter key.
- 3) Select a suitable LES then press the Enter key.
- 4) Select [Update Time] then press the Enter key.
- 5) Enter the current time then press the Enter key.
- 6) Select [Position] then press the Enter key.
- 7) Enter your current position in latitude and longitude then press the Enter key.
- 8) Select [Nature] then press the Enter key.
- 9) Enter applicable nature of distress then press the Enter kev.
- 10) Select [Course] then press the Enter key.
- 11) Enter your course then press the **Enter** key.
- 12) Select [Speed] then press the Enter key.
- 13) Enter your speed then press the Enter key.
- 14) Press the Esc key to show the [Update] window.
- 15) [Yes] is selected; press the Enter key to finish.
- 2. Open the cover of the **DISTRESS** button on the Terminal Unit IC-218 or the Distress Alert Unit/Received Call Unit IC-305.



Distress Alert/Received Call Unit IC-305

3. Press the **DISTRESS** button until (approx four seconds) the lamp in the button lights continuously. The distress alert will not be sent until the lamp in the button lights continuously and the audio alarm sounds. The message "Sending Distress Alert" appears on the screen while the distress alert is being sent.

HOW TO SEND A DATA REPORT AT **REGULAR INTERVALS**

- 1. Press the F5 and 1 keys to show the [Data Report] menu.
- 2. Press the appropriate numeric key to select a data report.

	Data Report	
Data Report Programming		
Status	OFF	
Report Length	Position and Course/Speed	
Destination		
DNID		
LES ID		
Member No.		
Activation	Regular Interval	
Interval Time	00:10	
Report Times	1 (: No Limit)	
Start Time1	:	
Start Time2	:	
Start Time3	:	
Start Time4	:	

- 3. Press the Enter key to open the status options window.
- 4. Select appropriate option then press the Enter key. OFF: Data report off **ON**: Enhanced Data Report (Data report w/confirmation) **ON**: Usual Data Report (Standard data report)
- 5. Select [Report Length] then press the Enter key.
- 6. Select appropriate option then press the **Enter** key. Position only: Own position Position and Course/Speed: Position, course and speed Position and Course/Speed with SEA INF: Position, course, speed, water temperature, tide, and depth
- 7. Select [DNID] then press the Enter key.
- 8. Select DNID desired then press the Enter key.
- 9. Select [LES ID] then press the Enter key.
- 10. Select LES ID desired then press the Enter key.
- 11. Select [Member No.] then press the Enter key.
- 12. Select Member No. desired then press the Enter key.
- 13. Select [Activation] then press the Enter key.
- 14. Select [Regular Interval] then press the Enter key.
- 15. Select [Interval Time] then press the Enter key.
- 16. Key in interval time then press the Enter key.
- 17. Select [Report Times] then press the Enter key.
- 18. Key in the report times, or press the **BackSpace** key to display "---" to select [No Limit] to transmit data until the Status setting is turned OFF. Press the Enter key.
- 19. Press the Enter key to close the window.

PUB. NO. OSE-56740-A (1206, DAMI) FELCOM18

