

SAILOR 6110 mini-C GMDSS



SAILOR 6110 mini-C GMDSS

User manual

Document number: 98-130753-B

Release date: April 2, 2012

Disclaimer

Any responsibility or liability for loss or damage in connection with the use of this product and the accompanying documentation is disclaimed by Thrane & Thrane. The information in this manual is provided for information purposes only, is subject to change without notice and may contain errors or inaccuracies.

Manuals issued by Thrane & Thrane are periodically revised and updated. Anyone relying on this information should acquire the most current version e.g. from thrane.com or from the distributor.

Thrane & Thrane is not responsible for the content or accuracy of any translations or reproductions, in whole or in part, of this manual from any other source.

Copyright

© 2012 Thrane & Thrane A/S. All rights reserved.

GPL notification

The software included in this product contains copyrighted software that is licensed under the GPL/LGPL. A copy of those licenses is included in this document in the last appendix. You may obtain the complete corresponding source code from us for a period of three years after our last shipment of this product, by sending a money order or check for DKK 50 to:

SW Technology/GPL Compliance,
Thrane & Thrane A/S,
Lundtoftegaardsvej 93D
2800 Kgs. Lyngby
DENMARK

Please write "source for product SAILOR 3027 GMDSS Terminal" or "source for product SAILOR 6006 Message Terminal" in the memo line of your payment.

You may also find a copy of the source at <http://www.thrane.com/foss>.

This offer is valid to anyone in receipt of this information.

Warranties

Any attempt to install or execute software not supplied by Thrane & Thrane on the devices in this system will result in the warranty being void. Any attempt to modify the software on these devices in a way not specified by Thrane & Thrane will result in the warranty being void.

Trademark Acknowledgements

- **Thrane & Thrane** is a registered trademark of Thrane & Thrane A/S in the European Union and the United States.
- **Inmarsat** is a registered trademark of the International Maritime Satellite Organisation (IMSO) and is licensed by IMSO to Inmarsat Limited and Inmarsat Ventures plc.
- **SAILOR** is a registered trademark of Thrane & Thrane A/S in the European Union, the United States and other countries.
- Other product and company names mentioned in this manual may be trademarks or trade names of their respective owners.

Safety summary

The following general safety precautions must be observed during all phases of operation, service and repair of this equipment. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture and intended use of the equipment. Thrane & Thrane assumes no liability for the customer's failure to comply with these requirements.

Observe marked areas

Under extreme heat conditions do not touch areas of the units that are marked with this symbol, as it may result in injury.



Microwave radiation hazards

During transmission the antenna in this system radiates Microwave Power. This radiation may be hazardous to humans close to the antenna. When the system is powered, make sure that nobody gets closer than the recommended minimum safety distance of 0.3 m (1 ft.).

Keep away from live circuits

Operating personnel must not remove equipment covers. Only qualified maintenance personal must make component replacement and internal adjustment. Under certain conditions, dangerous voltages may exist even with the cable removed. To avoid injuries, always disconnect power and discharge circuits before touching them.

Compass safe distance

Minimum safety distance: 5 m from the GMDSS Terminal.

About the manual

Intended readers

This manual is a user manual for the SAILOR 6110 mini-C GMDSS. The manual is intended for anyone who is using or intends to use this system. No specific skills are required to operate the SAILOR 6110. However, it is important that you observe all safety requirements listed in the beginning of this manual, and operate the system according to the guidelines in this manual.

Manual overview

Note that this manual does not cover installation of the system. For information on installation, refer to *SAILOR 6110 mini-C GMDSS, Installation manual [1]*. Part numbers for related manuals are listed in the next section.

This manual has the following chapters:

- **Introduction** contains an overview of the SAILOR 6110 and a brief description of each unit in the system.
- **Getting started** explains how start up the system. It also contains a short guide to the most important functions.
- **Using the system** explains how to set up and use the system with a SAILOR 6006 Message Terminal.
- **Service** contains information on software update and a short troubleshooting guide and explains how to check the status of the system.

Related documents

The below list shows the documents related to this manual and to the SAILOR 6110.

Ref	Title and description	Document number
[1]	SAILOR 6110 mini-C GMDSS, Installation manual	98-130752
[2]	SAILOR 6006 and SAILOR 6007 Message Terminal, Installation manual	98-130088
[3]	SAILOR 6101 and SAILOR 6103 Alarm Panel, Installation and user manual	98-130981
[4]	SAILOR 6081 PSU and Charger, Installation and user manual	98-130980
[5]	System 6000 GMDSS Console system, Installation manual	98-131571
[6]	THRANE 6194 Terminal Control Unit, Installation and user manual	98-131593
[7]	Moxa EtherDevice Switch, EDS-205A/208A Series, Hardware Installation Guide	1802002050023

Typography

In this manual, typography is used as indicated below:

Bold is used for the following purposes:

- To emphasize words.
Example: “Do **not** touch the antenna”.
- To indicate what the user should select in the user interface.
Example: “Select **SETTINGS > LAN**”.

Italic is used to emphasize the paragraph title in cross-references.

Example: “For further information, see *Connecting Cables* on page...”.

Contents

Chapter 1 Introduction

Welcome	1
System overview	2
System units	4
User interface	6
The Inmarsat C services	7

Chapter 2 Getting started

Registration	11
Initial configuration	12
Starting up the system	16

Chapter 3 Using the system

Sending a Distress Alert	20
Overview of SAILOR 6006 Message Terminal	23
Menu overview	27
Working with messages	28
Receiving EGCs	43
Printing, saving or deleting EGCs or messages	46
Network status	47
Managing the list of Contacts	50
Power status	55
Viewing system details	57
Changing regional settings and night mode	58

Changing the Distress Alert settings63
Changing the EGC settings67
Changing the Message settings70
Changing the Network settings 71
Position78
Testing Distress buttons in the system 81
Using the SAILOR 1252 Printer84

Chapter 4 Service

Getting support87
Updating software 88
Troubleshooting guide92
Status signalling94
Service and repair97

App. A GNU License texts

GNU General Public License 99
GNU Lesser General Public License 103

Glossary 109

Index 113


Introduction

Welcome

Congratulations on the purchase of your SAILOR 6110!

With the SAILOR 6110 you can send and receive data, including Distress Alerts, via satellite through the Inmarsat C network.

The drawing below shows an example of a SAILOR 6110 system.



This chapter has the following sections:

- *System overview*
- *System units*
- *User interface*
- *The Inmarsat C services*

System overview

GMDSS

Global Maritime Distress and Safety System or GMDSS is a communication system to enhance safety at sea. This global system comprises both radio and satellite based technology carriers, and is currently mandatory for all vessels of over 300 GT and vessels otherwise included in SOLAS (the International Convention for the Safety of Life at Sea).


Overall satcom GMDSS service is operated by Inmarsat and overseen by IMSO, the International Mobile Satellite Organization and adheres to the IMO, the International Maritime Organization.

The SAILOR 6110 is a GMDSS approved communication system designed for use with the Inmarsat C satellite network.

The SAILOR 6110 mini-C GMDSS

The Inmarsat C satellite network is the link between the SAILOR 6110 and the destination office. It uses four geostationary satellites to cover the world. For each satellite there is an NCS, Network Coordination Station, handling registration of the mobile unit (in this case the SAILOR 3027) in the Inmarsat C system.

Each NCS is associated with a number of LESs, Land Earth Stations, which handle the transmission between the mobile units and the destination office.



The SAILOR 3027 is connected to a SAILOR 6006 Message Terminal, where you can read and write messages and send Distress Alerts. This communication is transmitted via the SAILOR 3027 to/from the Inmarsat C satellite network.

System units

The basic SAILOR 6110 consists of the following units:

- SAILOR 3027 GMDSS Terminal.
Contains both transceiver, GPS receiver and omni-directional antenna for the Inmarsat C system. Connects to other equipment, primarily the SAILOR 6006, through a CAN interface carrying both power and bi-directional communication.



- SAILOR 6006 Message Terminal.
Enables you to send and receive messages, send Distress Alerts, monitor system status and test the system. The SAILOR 6006 has a touch-screen interface and comes with a SAILOR 6001 keyboard.



- SAILOR 1252 Printer.
Prints messages and reports from the SAILOR 6006.



- SAILOR 6101/6103 Alarm Panel.
Enables you to send Distress Alerts. SAILOR 6101 connects to Inmarsat C.



SAILOR 6103 connects to Inmarsat C, MF/HF and/or VHF.




For a more detailed description of the units, refer to the installation manual for the SAILOR 6110 mini-C GMDSS.

SSA option

The Ship Security Alert System provides ships with alarm buttons, which can be activated in case of a piracy or terrorist attack. The alarm is a covert signal that has no sound and no flashing lights, so it is not seen nor heard by any intruders on board the ship.

The SSA option consists of the THRANE 6194 Terminal Control Unit and three to six SSA alarm buttons and one test button. It connects to the SAILOR 6110 system through the CAN interface. The CAN interface also provides the power for the SSA option.

SAILOR 6110 mini-C GMDSS with SSA



For further information on the SSA option, refer to the manual for the THRANE 6194 Terminal Control Unit [6].

User interface

The main user interface for the SAILOR 6110 is in the SAILOR 6006 Message Terminal. With the SAILOR 6006 Message Terminal you can send and receive messages, send Distress Alerts, view system status and configure the system.



The Message Terminal has a touch-screen for operating the system. You can also use the keyboard, which is mandatory in GMDSS.



In most cases, you must also have a second Distress button, e.g. an alarm panel, in your system. For information how to use it, see the manual for your alarm panel.

For details on how to use the Message Terminal, see *Using the system* on page 19. To get started with the mini-C GMDSS, see *Getting started* on page 11.

The Inmarsat C services

The SAILOR 6110 supports the following services through the Inmarsat C system. For a description of these services, see the next sections.

- *Distress alerting and Distress priority messaging*
- *Enhanced Group Calling (EGC)*
- *Message transmission*
- *Position reporting*
- *Data reporting and polling*

Distress alerting and Distress priority messaging

If a ship or a crew is in grave and imminent danger, maritime Inmarsat C and some mini-C models are used to send a Distress Alert by pressing a dedicated Distress button.

The alert contains information on the ship's identity (Inmarsat C mobile number), ship's position (latitude and longitude), ship's course and speed, nature of Distress, date / time when the alert was sent and time when the ship's position was last updated.

All Distress Alerts are automatically routed through the addressed LES to an associated Maritime Rescue Coordination Centre (MRCC), which will establish communication with the ship and launch the search and rescue (SAR) operation the ship may need.

After sending the initial Distress Alert, if time permits, it is possible to send a more detailed Distress priority message to give more details about the Distress event and ask for the required assistance.

The Distress priority message should be sent via the same LES as the Distress Alert, to ensure that it is delivered automatically to the same MRCC.

Enhanced Group Calling (EGC)

The Inmarsat C system has a special capability known as Enhanced Group Call (EGC), which enables authorised information providers to broadcast messages to selected groups of ships. Reception by ships that are fitted with Inmarsat C or mini-C terminals is automatic. A special header is added by the system to the EGC message to indicate the group of mobile terminals or the geographical area to which the message is to be sent.

Two EGC services are available:

- EGC SafetyNET - the international safety service, which allows authorised maritime safety information (MSI) providers, such as meteorological offices, hydrographic officers and MRCCs to broadcast messages to all ships in certain geographical areas.

MSI includes navigational and meteorological warnings, meteorological forecasts and other urgent safety-related information, which is addressed to all ships in NAVAREA / METAREA, user-defined circular or rectangular area or coastal area.

Reception of SafetyNET messages is a mandatory function of the GMDSS equipment that is required to be carried in certain ships under the provision of the International Maritime Organisation's Safety Of Life At Sea (SOLAS) convention.

- EGC FleetNET - the international commercial service, which allows authorised information providers, such as commercial subscription services, shipping companies or governments to broadcast messages to selected groups of vessels, each of which has registered with the information provider and been added to a FleetNET closed group / network. The mobile terminals on these groups of vessels are identified by an ENID (EGC Network IDentification) common to the group.

For further information on EGC via Inmarsat C read the Inmarsat Maritime Communications Handbook, Chapter 6, or visit the Inmarsat Maritime Safety Services section of the Inmarsat website www.inmarsat.com.

Message transmission

Ship to shore: Text and data from Inmarsat C and mini-C terminals can be sent to:

- An e-mail address
- Any telex or fax (text, one way only) number
- Any computer connected to the public telephone and data networks (PSTN and PSDN), using a telephone modem number
- Another Inmarsat C / mini-C terminal
- A Short (or Special) Access Code (SAC).

The maximum message size is up to 10 kb for the GMDSS Terminal.

Shore to ship: Text and data can be sent via telex, e-mail and the data and telephone (PSDN / PSTN) networks. To be able to send messages to ships, a shore-based message originator needs to be registered (to have a commercial service agreement) with an Inmarsat C service provider of their choice.

Ship to ship: Messages can also be sent in a ship-to-ship direction from one Inmarsat C / mini-C terminal to another.

Position reporting

Most of Inmarsat C and mini-C models are integrated with Global Navigational Satellite System (GNSS) receivers, such as GPS, to provide highly reliable, round-the-clock position information of a ship, which can be used for position reporting.

The position reporting service is based on using the data reporting and polling protocol and allows a shore-based subscriber (base station or shipping company) to request position information from a vessel, as a single report or automatic reception at fixed intervals, e.g. every six hours.

A ship's terminal can also be programmed to send regular position reports to any desired destination.

The position report includes ship's identity, latitude, longitude, course, speed, date / time of the position report and time of the last position update.

In the mini-C GMDSS, the report is sent to a DNID (Data reporting Network Identification) that is effectively a mailbox created on some LESes. The GMDSS Terminal sends its reports to this mailbox and other tracking systems can then access and empty the mailbox. The mini-C GMDSS supports up to 64 DNIDs.

Up to 255 mobile terminals can use the same DNID, and the specific terminal is identified by a member number between 1 and 255.

The DNID must be created on the LES before the position-reporting feature can be used. Once the DNID account is created, the LES can download the DNID information to the desired terminals, thereby enabling them to send reports to the DNID.

Data reporting and polling

Inmarsat C users may need to acquire information (short data reports) from vessels, or to collect data automatically at fixed or variable intervals.

The data reporting service allows for the transmission of information, in packets of up to 32 bytes on request or at prearranged intervals from Inmarsat C or mini-C terminals, to shore-based customers.

Polling allows shore-based customers to interrogate an Inmarsat C or mini-C terminal or group of terminals by sending a special polling command. The polling command instructs a terminal or group of terminals to send a data report immediately, start sending regular reports, change transmission schedule of reports or perform another task of the polled terminal(s).

Getting started

This chapter explains how to register, start up and log on your SAILOR 6110. It has the following sections:

- *Registration*
- *Starting up the system*

Registration

Before using the SAILOR 3027 GMDSS Terminal on the Inmarsat-C system you must register the terminal to the system. In most cases the distributor has already filled in the SARF (Service Activation Registration Form) for your SAILOR 3027 when you receive your SAILOR 6110 mini-C GMDSS.

For details on registration, see the Installation manual for the SAILOR 6110 mini-C GMDSS.

After registration you must use a Message Terminal to set up the mobile number in the SAILOR 3027. See *Setting the mobile number in the SAILOR 3027* on page 71.

Initial configuration

Note

The initial configuration may already have been done during installation of the system. If so, please skip this section.

For configuration you must have a keyboard connected to the Message Terminal.


To select the mini-C software

The first time the Message Terminal is switched on, you are asked to select the Message Terminal software to use. The Message Terminal can be used for Radiotelex or for Inmarsat C.

Important

Make sure you select the correct software for the system you are going to use. Once you have selected the software you cannot change it back!

Enter “1” for Inmarsat C.




After entering Inmarsat C, the Message Terminal automatically restarts as an Inmarsat C message Terminal.

To configure a duplicated system

If you have a duplicated system, you have to set up which system is the primary and which one is the duplicated system. Do as follows:

1. During startup of the Message Terminal and before the main screen appears, press **Esc** on the connected keyboard.




2. Use the down key to highlight the configuration line and then press **Enter** to continue.
3. To configure a duplicated system, select **Select GMDSS system**.¹



1. "Calibrate touch screen" is only used for Message Terminals with resistive touch screen (early models).

4. Type in the password if you are prompted. The password is 1234.
5. Select whether the current mini-C GMDSS should be the primary or duplicated system and then select **Store**.



6. Confirm your selection.


Important

Remember to set the Message Terminal in the other part of the duplicated system to the opposite of this one.

In the Message Terminal, under **System > About**, you can see whether the system is a Primary or Duplicated system.



If you have an Alarm Panel in the system, the primary and duplicated systems will appear in the Alarm Panel as Inm-C 1 and Inm-C 2 respectively.



Starting up the system


Powering the system

When all units are connected correctly and you have registered the SAILOR 3027, do as follows to power the system:

1. Make sure the power source is on.
2. Switch on the SAILOR 6006.
 - Use the power switch in the right side of the SAILOR 6006, or
 - if you have installed a remote on/off switch, use that instead.




The SAILOR 6006 starts up and sends a signal to switch on the SAILOR 3027. The SAILOR 6006 shows the current status in the upper right corner of the display.



For an overview of the user interface, see *Overview of the screen* on page 24.

Logging into the satellite network

If the system was not already logged into the Inmarsat C network, it logs in automatically at startup. The upper right corner of the display shows if the system is logged on.



If, however, the selected satellite is no longer available, you must manually select another satellite to log into.

To log into the satellite network manually, do as follows:


1. When the main menu of the SAILOR 6006 appears, select **Network**.



2. On the **Network Status** page select **Login**.



3. Select the Ocean Region to which you want to log in.
If the selected satellite is available, the system will now log on.
When the display shows the Ocean Region and the position, and there is a green check mark at the satellite symbol, the system is ready for use.



Note | The Ocean Region is only displayed if the system is idle and there are no errors - otherwise the text will show the current status.

Using the system

This chapter describes how to operate the SAILOR 6110, primarily using the SAILOR 6006 Message Terminal. It has the following sections:

- *Sending a Distress Alert*
- *Overview of SAILOR 6006 Message Terminal*
- *Menu overview*
- *Working with messages*
- *Receiving EGCs*
- *Printing, saving or deleting EGCs or messages*
- *Network status*
- *Managing the list of Contacts*
- *Power status*
- *Viewing system details*
- *Changing regional settings and night mode*
- *Changing the Distress Alert settings*
- *Changing the EGC settings*
- *Changing the Message settings*
- *Changing the Network settings*
- *Position*
- *Testing Distress buttons in the system*
- *Using the SAILOR 1252 Printer*

For details on the Inmarsat C services, see *The Inmarsat C services* on page 7.

Sending a Distress Alert

Important

Only send a Distress Alert if you are in immediate danger!
The Distress Alert can be compared to a MAYDAY call.

The procedure below is the same on the SAILOR 6006 Message Terminal as on the SAILOR 6101/6103 Alarm Panel.

To send a Distress Alert, do as follows:


1. Open the cover for the Distress button.
2. Press and hold the button until the light is steady and the buzzer stops (more than 3 seconds).



During this time the button light flashes and the buzzer sounds. After 3 seconds the red light goes steady on and the buzzer is silent. The display shows that the message is being sent.



The display also shows when the Distress Alert is acknowledged from the LES. **Write down the LES number** - you must use the same number when you send a Distress message with more information for the MRCC.



The below table shows the behaviour of the Distress button on the SAILOR 6006.

Behaviour	Meaning
Button light flashes, buzzer sounds	The Distress button is pressed. Hold until light and sound changes (more than 3 seconds).
Button light constant, buzzer is silent	The Distress Alert is being sent (normally within 10 to 30 seconds)
Button light shortly off every 15 seconds	The Distress Alert is confirmed

Important

The MRCC normally sends a message to the alerting unit to gather more information about the situation.

If at all possible, respond to such messages with a Distress message sent to the same LES that was used for the Distress Alert.

The LES used for the Distress Alert is shown in the Distress popup windows. An example is shown in the previous page.

For information on how to send a Distress message, see *Writing a Distress priority message* on page 28.

The MRCC may also send Distress EGCs to other ships in the area to request assistance (typically as Distress Relay or SAR Coordination request).

See also *Changing the Distress Alert settings* on page 63.

Clearing distress indications

If you want to turn off all distress indications while a Distress Alert is still active, do as follows:

Note

This function will only turn off the visual and audible indications on board. It will not cancel the transmission of the Distress Alert.

1. On the SAILOR 6006, select **Distress**.
2. Select **Status**.



3. Select **Clear distress indications**.

Overview of SAILOR 6006 Message Terminal


Buttons in the front panel

The buttons in the front panel have the following functions:

Control	Function
	The Distress button is used to send a Distress Alert through the connected SAILOR 3027 terminal. See <i>Sending a Distress Alert</i> on page 20.
	The Test button is used to test the lights and sound in the buttons on the SAILOR 6006.
	The Dim button is used to dim the light in the SAILOR 6006. Push and hold to dim more/less. Each new push changes direction between more and less.
	The mute button is used to mute the SAILOR 6006 and connected equipment, such as alarm panels.
	<p>Without remote on/off: To switch on: Push the button To switch off: Push and hold for 2 seconds</p> <p>With remote on/off: To switch on and off: The Power button cannot be used normally; use the remote on/off switch to switch the SAILOR 6006 on and off. To restart the terminal: Push and hold for 2 seconds.</p>

Overview of the screen

Below is an overview of the main screen in the SAILOR 6006.



- **Time (UTC):** This is the current time of day received with the position data. The presentation format can be changed under System > Settings > Regional settings.
- **Name of current page:** In each submenu this field shows the name of the page.
- **Status field:** This field shows a short status message next to the Status/warning icon.

- **Status/warning icon:** This icon can show:



Status OK



Warnings pending



Critical error pending

For details of warnings and errors, see *Information of events* on page 94.

- **Main menu items:** Select these items to access the submenu. For an overview of the menu system, see *Menu overview* in the next page.
- **Power status:** Shows a short status of the backup battery.

Navigating the user interface of the SAILOR 6006

To navigate and select items in the user interface you can do one of the following:

Touch screen: Select items by touching them with your finger on the screen of the SAILOR 6006. Items in a grey frame such as in the example below can be selected by touching anywhere within the frame.

13:49 UTC **DISTRESS SETTINGS** Indian Ocean 55°47.61'N 012°31.40'E

Distress Alert nature Nature Undesignated

Distress Alert Land Earth Stations

Atlantic Ocean Region West	004 Eik
Atlantic Ocean Region East	104 Eik
Pacific Ocean Region	204 Eik
Indian Ocean Region	304 Eik

Distress Alert position, course and speed

Position	Using latest GPS data
----------	-----------------------

Keyboard: Use the tab and arrow keys to navigate through items and press **Space** to select them. When an item has an underlined letter, you may type Alt + <the underlined letter> to select the item, e.g. type Alt+S to select the System menu from the main screen.


To sort a list

In lists, such as the message Inbox or the Contacts list, you can sort the list by selecting the heading of the column you want to sort by. E.g. to sort the names in the Contacts list, select Name. Select it again to toggle between ascending and descending order.



Menu overview

The below drawing shows an overview the menu system of the SAILOR 6110 system.



Note:
Menu items in grey colour are only available if Cyrillic characters are enabled under System > Settings > Regional settings > Cyrillic.

Using the system

The items in the menu overview are described in the following sections. Items marked * are described in the installation manual for the SAILOR 6110 system.

Working with messages

Writing a Distress priority message

Note

Distress priority messages are sent to the MRCC only.

Distress priority messages must be written in English.

To write a Distress priority message, do as follows:

1. From the main menu, select **Message**.



- At the bottom of the page, select **New** and then select **New Distress message**.




A popup window appears.



- Read the message and select **Yes**.

The Distress message editor opens.



4. Use a keyboard to type your message text, or touch the screen and select the soft keyboard that appears in the top right corner of the display. The text must be in English. Note that Cyrillic characters cannot be selected for a Distress message.
5. When the message is ready to be sent, select **Send**.



A popup window appears.




6. Select the LES to be used for sending the message, or use the already selected LES.

Important

The LES for the Distress priority message must be the same as the LES used from the start of the ongoing communication session.

7. Select **Send**.

You get a message saying: “Message scheduled for transmission”, and later: “Distress message initiated”.



8. Select **OK**. The message is sent as soon as the network allows it.

Note | Distress priority messages are sent to the MRCC only.

When the message is acknowledged you get a popup message.

You can also check the status of your message in the Outbox and Sent Items.

The message is moved from the Outbox to Sent items when it is sent, but it may not have been acknowledged yet. This is indicated by a question mark as shown below.



When the question mark changes to a check mark, the message has been acknowledged.



Writing a routine priority message

Note


You can enable the use of Cyrillic characters under **System > Settings > Regional settings > Cyrillic**. With Cyrillic characters enabled, you can change the keyboard to a Cyrillic keyboard for use in your message. For details, see *Using Cyrillic characters* on page 60.

To write a routine priority message, do as follows:

1. From the main menu, select **Message**.



2. At the bottom of the page, select **New**.



3. If you just want to type your text in the editor without changing the encoding, select **C**ontinue, skip the next 2 steps and go to step 6.



4. If you want a different encoding of the message, select **N**ew message instead of **C**ontinue. Then select the encoding you want.




Note


You can also change the encoding at a later stage by selecting the encoding in the top right corner of the message page and then select what you want to convert to.

If you have enabled Cyrillic characters, the encoding types for Cyrillic characters also appear in the list. For details, see *Using Cyrillic characters* on page 60.

- If you want to send a data file in stead of typing in text, select **New message > Data file (8-bit)**, browse to the file you want to send and select it. The filename appears in your message. Continue to step 7.



- Use a keyboard to type your message text, or touch the editor field and select the soft keyboard in the top right corner of the display.



Note If you want to save your message without sending it, you can save it as a file. See the next section *Options for writing and sending messages* on page 39.


7. Select the tab page **To...** and then select the Contacts icon.



8. Select the recipient(s) of the message from the Contacts¹ list. Then select **OK**.


Note

If you select more than one recipient, the address type must be the same for all recipients. The system does not support different address types for one message.



1. For information on how to edit the Contacts list, see *Managing the list of Contacts* on page 50.


9. Select the tab page **CC** or **BCC** at the top of the message editor if you want someone to receive a copy of the message. Then select or type in the recipient(s).



10. Select the tab page **Subject** and type a subject or title for your message.
11. When the message is ready to be sent, select **Send**.



12. Select the service provider to be used for sending the message, or use the already selected service provider.



Note Thrane & Thrane does not take responsibility for the correctness of the estimated payload for your message.

13. If you want confirmation when your message is received, select **Confirmation**.
14. Select **Send**.
You get a message saying “Message scheduled for transmission”. Select **OK**. The message is sent as soon as the network allows it.

Options for writing and sending messages



The **Options** menu in the right side of the **New message** page offers the following options when writing a message:

- **New message**
 - Telex (5-bit). Select this option if you want the message to be as small (and fast) as possible. Note that no special characters can be used, and all letters are converted to capital letters.
 - ASCII (7-bit). Select this option if size and speed are not very important and/or you want to be able to use special characters and small letters.
 - Data file (8-bit). Select this option if you want to send a data file instead of writing text in the editor.
 - If Cyrillic characters are enabled, you get some extra options. See *Using Cyrillic characters* on page 60.
- **New Distress message**
Opens the Distress message editor so you can write a Distress message.
- **Load**
Allows you to browse for a text file to load into the message editor.
- **Save**
Allows you to browse to or type in a location where you can save your message to a file. If, for example, you have written a draft message that you want to send later, you can save the message and then load it back into the editor when you want to send it.
- **Print**
Prints the text in the message editor on the connected printer.

Viewing messages in the Inbox


The Message icon in the main menu shows how many unread messages are in the Inbox.

Note | The Inbox can hold 1000 messages. The oldest messages are automatically deleted when this limit is exceeded.



To view the messages in the Inbox, do as follows:

1. At the bottom of the **MESSAGE** page, select **Inbox**.



In front of each message one of the following icons is shown:



The message is unread



The message has been read



Distress priority message (unread)



Distress priority message (read)

Apart from the icons, the Inbox shows:

- the name of the sender if listed in your Contacts, otherwise the e-mail address or number of the sender. If neither is known: “No address”.
- the subject, if any.
- the time and date of the message.

Note

You can sort the Inbox by selecting the top of the column you want to sort by.

2. Select the message you want to read.

For information on how to delete, print or save messages, see *Printing, saving or deleting EGCs or messages* on page 46.

Viewing messages in the Outbox

To view messages in the Outbox, click **Outbox** at the bottom of the **MESSAGE** page.



The Outbox holds messages that are scheduled for transmission, but have not yet been sent.

Select a message to see the contents.

Viewing Sent items

Note Sent items can hold 1000 messages. The oldest messages are automatically deleted when this limit is exceeded.

To view your sent messages, click **Sent Items** at the bottom of the **MESSAGE** page.



The Sent Items page shows all messages that have been sent from the SAILOR 3027, including Distress messages.

Note You can sort the list by selecting the top of the column you want to sort by.

Select a message to see the contents.

The icon next to the message can show the status of the message:



Sent Distress message is not yet acknowledged.



Sent Distress message is acknowledged.



Only if Confirmation is requested: Sent message is not yet acknowledged.



If Confirmation is requested: Sent message is acknowledged.
If Confirmation is not requested: Message is sent.

Receiving EGCs

Viewing incoming EGCs

Note You can receive various types of EGCs in the SAILOR 6006. For details about how to set up which EGCs to receive and which EGCs to print, see *Changing the EGC settings* on page 67.

The SAILOR 6006 shows incoming EGCs.

Note The EGC Inbox can hold 1000 EGCs. The oldest EGCs are automatically deleted when this limit is exceeded.

To view EGCs, do as follows:

1. Select **EGC** from the main menu.



2. Select **Inbox** (may already be selected).



Apart from the time and date of the EGC, the list of incoming EGCs can show the following icons:



SafetyNET EGC. Meteorological warning, navigational warning, coastal warning and meteorological forecast.



SafetyNET EGC. Shore to ship Distress Alert and search and rescue coordination



FleetNET EGC



System EGC



Default EGC. Only used if the EGC type is unknown.

The status of each EGC is shown with one of the below icons:



The EGC is unread



The EGC has been read



Distress or Urgent priority EGC (unread)



Distress or Urgent priority EGC (read)

3. Select an EGC to see the contents.

Note

You can sort the EGC Inbox by selecting the top of the column you want to sort by.

For information on how to delete, print or save EGCs, see *Printing, saving or deleting EGCs or messages* on page 46.

Printing, saving or deleting EGCs or messages

Use the tools symbol  to print, delete or save EGCs or messages. You can use the tools symbol from within an EGC or message or from the list of EGCs or messages (Inbox, Outbox or Sent items).

From the Inbox, Outbox or Sent items

To delete or save messages or EGCs from the Inbox, Outbox or Sent items, do as follows:

1. Click  in the lower left corner of the display.
2. Select the messages or EGCs you want to delete or save.
You may use **Select all** to select all items or **Clear all** to remove all selections.
3. Select **Delete** to delete the selected messages or EGCs or **Save** to save the selected messages.


From within a message or an EGC

To delete, print or save a message or EGC, do as follows:

1. Select the message or EGC you want to delete, save or print.
2. Select  in the corner of the display.
3. Select **Delete**, **Print** or **Save**.


Network status

The top right corner of the display shows a short text about the current status.



To view a more detailed network status, do as follows:

1. Select **Network** from the main menu.
2. Select **Status** at the bottom of the page.



Logging into and out of the network

To log into the Inmarsat C network, select **Login** from the lower left side of the **NETWORK STATUS** page and select the region you want to log into. If you just want to use the region with the best signal, use Scan instead (see the next section).

To log out of the network, select **Logout** from the lower left side of the **NETWORK STATUS** page and select **OK**.

Scanning the network

If you want the system to select the ocean region with the best signal, select **Scan** in the **NETWORK STATUS** page. The system will then scan for the best signal and log into that ocean region. Note that the scanning process may take a long time, because all ocean regions are scanned.

Clearing the current protocol

If you want the system to immediately stop transmitting, select **Clear** in the **NETWORK STATUS** window.

The current protocol is then cleared, and any ongoing transmission is stopped.

Link test

Note

To test basic system connectivity, we recommend that you send a short message to yourself instead of using the link test. For details on how to send a message, see *Writing a routine priority message* on page 33.

Because the link test has low priority in the network, it takes a long time for the system to complete the test, and during this time the system has limited functionality.

If you still want to run a link test, first make sure the SAILOR 3027 is properly commissioned and logged in. The top right corner of the Message Terminal display shows the status.

To run a link test using the Message Terminal, do as follows:

1. In the Message Terminal display, select **Network > Status > Link test...**
The Link test window shows the result of the latest link test if any.

2. Select **Perform link test**.

3. Select **Yes**.

A window shows **Link test in progress**. When the test is complete, the window shows the results of the test.

4. Select **OK** to exit the Link test window.

Managing the list of Contacts

To manage your list of contacts, select **Contacts** from the main menu.



The list of Contacts opens.



For each contact you can see the type and address.


From the bottom of the Contacts list you can add, edit or delete selected contact(s)

You can also access and manage your Contacts from within a message, by selecting the Contacts icon from the To... tab.

To add a new contact

Do as follows:

1. At the bottom of the **CONTACTS** list, select **New**.



2. Type in the name of your contact.
3. Select the **Address type** from the drop-down list.
4. Type in the details for your contact. The format of the address/number depends on the selected address type. See the table on the next page.
5. Select **OK**.

The list is updated with the new contact.


Message formats and presentation:

Type	Format of number	Example	Presentation
E-mail	Standard e-mail address	info@thrane.com	5, 7 or 8 bit
Telex	Country code + subscriber no.	0045 99999999	5 or 7 bit
Fax	Country code + subscriber no.	0045 99999999	5, 7 or 8 bit
Inmarsat-C mobile	Mobile number	492388999	5, 7 or 8 bit
PSTN modem	Country code + subscriber no.	0045 99999999	5, 7 or 8 bit
Special access code	Predefined codes: <ul style="list-style-type: none"> • 32 - Medical Advice • 33 - Technical Assistance • 38 - Medical Assistance • 39 - Maritime Assistance • 41 - Meteorological Reports • 42 - Navigational Hazards and Warnings • 43 - Ship Position and Sail Plan Reports 	32	5, 7 or 8 bit
X.25	DNIC (country code) + subscriber no.	2380 99999999	5, 7 or 8 bit

To edit a contact

Do as follows:

1. In the **Contacts** window, select the contact you want to edit.
2. Select **Edit**.



3. Edit the details.
See the previous section for information on the contact details.
4. Select **OK**.

To delete a contact

Do as follows:

1. In the **Contacts** window, select the contact(s) you want to delete.
2. Select **Delete**.
3. Select **Yes** to confirm.

Power status

The bottom left corner of the display shows a short status of the backup battery.




- Negative current means the battery is supplying power.
- Red numbers mean that the values are outside normal operating range.

For a more detailed power status, do as follows:

1. Select the battery symbol in the bottom left corner or select **System** from the main menu and then **Power** at the bottom of the page.



2. To view the battery settings, select **Settings**.



Important

The default battery settings are suitable for most installations. Do not change these settings unless you have a special battery type or installation that requires different settings. Only skilled personnel should change the power settings, which are password protected. Refer to the installation manual for the SAILOR 6110 system for details.

Viewing system details

To see the type and software version of the units in the system, do as follows:

1. Select **System** from the main menu.
2. Select **About** at the bottom of the page.

This page shows name, serial number and software version of each system unit. It also shows whether the system is a primary or duplicated system.



Select one of the units to see more details.



Changing regional settings and night mode

1. Select **System** from the main menu.



2. Select **Settings** at the bottom of the page.



Changing the date and time settings

To change how date and time is displayed in the message terminal, do as follows:

1. Select **Regional settings** from the **SYSTEM SETTINGS** page.



2. Select the format for date and time and select **OK**.

Using Cyrillic characters

Enabling Cyrillic characters

To enable the use of cyrillic characters in messages, do as follows:

1. Select **Regional settings** from the **SYSTEM SETTINGS** page.



2. Select **Cyrillic** and then **OK**.


To use Cyrillic characters

When Cyrillic characters are enabled, you can change your keyboard to a Cyrillic keyboard for use in the message editor.

Note | The physical keyboard and the on-screen keyboard are independent of each other. What you set up in one keyboard will not affect the other one.


1. First select the encoding you need. You can do this either
 - when you start a new message (**Message > New message**)
 - from the message editor (**Options > New message**)
 - from the message editor under the encoding format in the top right corner, as shown below.

There are currently three encoding formats for Cyrillic characters.



2. After selecting the encoding:
 - **If you are using a physical keyboard:**
Press **Alt + Shift** on the keyboard to toggle between Cyrillic and latin characters.
 - **If you are using the on-screen keyboard** in the message editor:
Touch the screen and then touch the keyboard symbol that appears in


the message editor. To toggle between Cyrillic and latin characters, touch **[CY]** in the bottom left corner of the on-screen keyboard.



Changing the ambient light limit for night mode

To change the light intensity at which the screen should enter night mode, do as follows:

1. From the **System > Settings** menu, select **Screen settings**.



2. Use the arrows or select and drag the pointer until the right light intensity for shifting to night mode is achieved.
3. Select **OK**.
The screen will automatically shift to night colours when the ambient light intensity falls below the selected limit.

Changing the Distress Alert settings

You can temporarily change the settings for your Distress function.

Note

The Distress Alert Nature and the Distress Alert Position, Course and Speed settings are only valid for the current Distress Alert or maximum one hour. Then these settings are returned to the default settings.

The entered Distress LESs remain in the system.

Default settings:

- Distress Alert Nature: Unspecified
- Distress Alert Land Earth Stations: 0, 0, 0, 0
("0" means the LES is automatically selected by the SAILOR 3027).
- Distress Alert Position, Course and Speed: Using latest GPS data

Distress Alert nature

To change the announced nature of the Distress Alert, do as follows:

1. From the main menu of the SAILOR 6006, select **Distress**.

2. Select **Settings**.



3. Select **Distress Alert nature**.

4. Select the nature of the Distress Alert and select **OK**.



Distress Alert Land Earth Stations

Default setting: 0, 0, 0, 0

To change the LESs to be used for the Distress Alert, do as follows:

1. From the **DISTRESS SETTINGS** menu, select **Distress Alert Land Earth Stations**.
2. Type the LES number for each Ocean Region.



3. Select **OK**.

Distress Alert position, course and speed

Default setting: **Use GPS position.**

Note

Do not change this setting unless you have good reasons to do so. It is normally best to show your current GPS position when sending a Distress Alert.

You may need to change the position, e.g. if the person(s) that need help are no longer on board the ship (man overboard).

To change the position, course and/or speed to manually entered values, do as follows:

1. From the **Distress Settings** menu, select **Distress Alert position, course and speed.**
2. Select **Use manual position.**



3. Type or select the new values and select **OK.**

Changing the EGC settings

Reception of EGCs

To change the settings for reception of EGCs, do as follows:

1. From the main menu, select **EGC**.
2. Select **Reception**.



3. To change the additional areas from which you want to receive meteorological or navigational EGCs, select **Additional NAVAREAS /METAREAS**.

Then select or type in the numbers of the areas from which you want to receive EGCs, and select **OK**.

Note

You always receive EGCs from the area in which you are located. The areas selected here are additional areas.


4. To change the Coastal Warning Areas and services, select **Coastal Warning Areas and Services**. Then type in the new area and select the services you want to receive. Then select **OK**.
5. To change the types of EGC service you want to receive, select **EGC services**. Then select the EGC services you want to receive and select **OK**.

Note

Some SafetyNET EGCs cannot be disabled due to IMO SOLAS regulations.



6. To enable or disable your FleetNET ENIDs, select **FleetNET ENIDs**, then select the ENIDs you want to enable or disable and select **OK**.



FleetNET ENIDs are the EGC Network IDs for the FleetNET groups or networks of which the vessel is a member.

Automatic print of EGCs

You can set up the SAILOR 6006 to automatically print certain types of EGC. Do as follows:

1. From the bottom of the **EGC** page, select **Settings**.



2. Select **Auto print received EGCs**.
3. Select the types of EGC you want to print automatically and select **OK**.



Note | **SafetyNET urgency + distress** EGCs cannot be disabled - they are automatically sent to the printer.

Changing the Message settings

Automatic print of messages

You can set up the SAILOR 6006 to automatically print certain types of messages. Do as follows:

1. From the main menu select **Message**.
2. Select **Settings**.



3. Under **Auto print received messages**, select **Routine** if you want to print Routine messages automatically when they arrive.

Note | Automatic print cannot be disabled for Distress messages.



4. Select **OK**.

Changing the Network settings

Network ID

Setting the mobile number in the SAILOR 3027

After registration, the Inmarsat mobile number (network ID) must be set up in the SAILOR 3027. Do as follows:

1. From the main menu of the SAILOR 6006 select **Network**.
2. Select **Settings**.



3. Check that the mobile number listed under Network ID matches the mobile number in the documentation from your airtime provider.



4. If the mobile number is not correct, select **Network ID** and change the number.



5. When the number is correct select **OK**.

DNIDs and data reporting


DNIDs (Data reporting Network Identification) are used for position reporting and data reporting. The DNIDs for a terminal must be created on a LES and downloaded to the terminal. When a DNID is downloaded to the SAILOR 3027 GMDSS Terminal, the terminal will send reports to a mail box on the LES according to the programs defined for the DNID. The mini-C GMDSS supports 64 DNIDs. For further information, see *Position reporting* on page 9 and *Data reporting and polling* on page 10.

You can see the DNIDs and their associated programs in the Message Terminal. Do as follows:


1. From the **NETWORK SETTINGS** page, select **DNIDs and data reporting**.



2. To see the program(s) associated with a DNID, select the DNID and select **View programs**.




The Programs window opens.



3. Select the program you want to see.
In the right side of the Programs window you can see information about the selected program. The programs can be:
 - **Interval programs** instructing the GMDSS Terminal to send reports at regular intervals. The Interval programs are mostly remote programs, but may also be programs managed and defined locally, e.g. with a terminal program.

- **Event programs** instructing the GMDSS Terminal to send reports when certain events occur.



Network Coordination Stations

Adding Network Coordination Stations

If you need to add a Network Coordination Station (NCS), do as follows:

1. In the **NETWORK SETTINGS** page, select **Network Coordination Stations**.



2. Select **New**.



3. Type in the ID and channel number of the new NCS.
4. Select **OK**.

Editing Network Coordination Stations

If you need to edit the information for a Network Coordination Station (NCS), do as follows:

1. In the **NETWORK SETTINGS** page, select **Network Coordination Stations**.
2. In the left column, select the NCS you want to edit.

Note | 044, 144, 244 and 344 cannot be edited nor deleted.

3. Select **Edit** in the right side of the page.




4. Change the ID and channel number as needed.



5. Select **OK**.

Position


To view your current position, course and speed, select **Network** from the main menu, and then **Position** at the bottom of the page.




Entering a manual position

If there is no synchronization with the positioning system, you can enter a manual position. To enter a manual position, do as follows:

1. Under **Network** select **Settings** at the bottom of the page.



2. Select **Manual position**.



3. Enter the current position data, course, speed and UTC time.
4. Select **OK**.

The manually entered position data will be used by the system until the automatic position data is available again.

Testing Distress buttons in the system

With the SAILOR 6006 you can test all **Inmarsat C** Distress buttons connected in your SAILOR 6110 system.

To test the Inmarsat C Distress buttons in the system, do as follows:

1. In the Message Terminal display, select **Distress**.




2. Select **Status** at the bottom of the page.



3. Select **Test Distress buttons**.

The test is initiated.



Wait until the following window appears.

Important

Before pressing any Distress buttons, make sure the display of the SAILOR 6006 shows Test in progress. Otherwise you may accidentally send a real Distress Alert!



As long as the **Test in progress** window is showing, you can use Distress buttons connected to the system under test, without sending a real Distress Alert.

Note

Before pressing any Distress buttons, check the units as follows:

- On the alarm panel, make sure the display shows “Test” next to the Inm C unit that is active (marked with a bullet), before pressing the **Inm-C Distress** button.
- On the Message Terminal, make sure the display shows “Test in progress” before pressing the **Distress** button on the Message Terminal.


4. Test the **Inmarsat C** Distress buttons on the connected units and on the Message Terminal by pressing them as you would in a real Distress situation.

Important

Only **Inmarsat C** Distress buttons are included in this test. **Do not** press any other Distress buttons, unless it is a distress situation!

The light and buzzer in the Distress buttons should work the same way as in a real Distress situation. For details on the Distress buttons, see *Sending a Distress Alert (SAILOR 6150 only)* on page 60.

5. When you have finished testing, or you need to send a real Distress Alert, press **Cancel** in the **Test in progress** window.



Using the SAILOR 1252 Printer

In the SAILOR 6110, the printer is primarily used to print EGCs and Safety messages from the SAILOR 6006.

For information on how to print EGCs and messages, see *Printing, saving or deleting EGCs or messages* on page 46 and *Automatic print of EGCs* on page 69.


Printer indications in SAILOR 6006

The SAILOR 6006 Message Terminal shows a warning if:

- the printer is not connected
- the printer is out of paper
- the paper is low
- there is an error in the printer
- the printer is off-line

Front panel

The below drawing shows the front panel of the SAILOR 1252 Printer.



The next pages describe the functions of indicators and buttons on the printer front panel.

Indicators

The below table shows the function of each indicator.

Indicator	Behaviour	Function
SELECT	Constant light Off Flashing, and ALARM is off Flashing, and ALARM is on	Printer is on-line Printer is off-line Printer is in sleep mode Fault
ALARM	Constant light, and SELECT is off Constant light, and SELECT is flashing Flashing, and SELECT is on	Out of paper or paper jam (Cut sheet feeder only) Fault Printhead temperature protection circuit, firmware protection of line feed or space motor is operating. Normal print operation will resume after a cooling period.
POWER	Constant light	The printer is connected to the supply and is switched on.
PITCH		Shows the current character pitch selected.
MODE		Shows the current print mode selected - NLQ, Utility, HSD (HSD is SSD if 12cpi is selected).

Buttons

Normal functions

Indicator	Normal function
LINE FEED	Advances the paper one line for each press.
FORM FEED	Advances the paper to the next top of form (TOF) or ejects any single sheet paper from the printer.
TOF SET	Sets new top of form position.
SELECT	Sets printer on-line or off-line
PITCH	Changes the character pitch setting (cpi)
MODE	Changes the print style setting.

Additional functions if pressed at power on

Indicator	Function if pressed at power on
SELECT	Enters the printer's Menu Mode.
TOF SET	Selects the print pitch as 17cpi.
LINE FEED	Initiates the printer self test.
SELECT and LINE FEED	Initiates the printer's continuous rolling ASCII test.
SELECT and FORM FEED	Prints all data and control commands received as HEX codes for fault finding.

Service

This chapter gives guidelines for updating software and for troubleshooting and provides an overview of the different means of status signalling. It has the following sections:

- *Getting support*
- *Updating software*
- *Troubleshooting guide*
- *Status signalling*

Getting support

If this manual does not provide the remedies to solve your problem, you may want to contact your Airtime Provider or your local distributor.

To help with the troubleshooting, please generate a diagnostic report as described in the next page, and enclose the diagnostic report file when asking for support.

Airtime support

If you need assistance from your Airtime Provider, check your Airtime subscription documents for a contact number to call.

System support

If you need assistance with problems caused by one of your system units, please call a distributor in your area.

A list of certified partners and distributors is available on Thrane & Thrane's web site: www.thrane.com. Select **Maritime** and select **Where to buy** from the top menu bar.

Generating a diagnostic report

To generate a diagnostic report, do as follows:

1. Select **System**.
2. Select **Advanced** at the bottom of the page.



3. Select **Generate diagnostic report**.
4. Choose the location where you want to save the file. You can save the file to a USB memory stick connected to the Message Terminal.

Updating software

Before updating software

Tool for software update

To update software in the SAILOR 6110 system units (e.g. the GMDSS Terminal, the Message Terminal and/or the Alarm Panel), use the TMA (ThranelINK Management Application). For information on how to install the TMA, see the next sections.

The ThraneLINK Management Application

The ThraneLINK Management Application (TMA) is a Windows program that provides monitoring and software update of connected Thrane & Thrane devices with ThraneLINK support. The devices must be on the same LAN.



Installing the TMA

PC requirements

- Standard PC with Windows 7 or Windows XP and Ethernet
- Make sure that you have administrator rights for the PC.

Installation

To install the TMA, do as follows:

1. Go to www.thrane.com > **Downloads**, locate the TMA software package and download it to your PC.

2. Extract the files from the zip file.
3. Click **setup.exe** to start the installation wizard.
If a Windows Security Alert pops up click **Allow access** (Windows 7) or **Unblock** (Windows XP).
4. Follow the instructions in the wizard.

When the wizard is complete, a TMA icon appears on your PC desktop. You can also find the TMA under Programs > Thrane > TMA.



If you have problems with your Firewall settings, please refer to the TMA quick guide, also available at www.thrane.com > **Downloads**.

Updating software with the TMA

To update software in a ThraneLINK product, do as follows:

1. Connect the PC to the LAN with the Thrane & Thrane products for which you want to update software.
2. Click the TMA icon on the PC's desktop. The program starts and displays the ThraneLINK products found on the network.
If a Windows Security Alert pops up click **Allow access** (Windows 7) or **Unblock** (Windows XP).

3. Insert a USB memory stick with the new software version into a USB connector in the PC.¹

The TMA automatically discovers the new software version(s) and a software update icon flashes next to the unit(s) for which the software can be installed.




4. From the main page of the TMA, select the product you want to update.

-
1. If the new software is not on a USB stick, you can point to the location of the software by selecting the tool icon in the **Software update** page and entering the location of the software.





5. Select **Software update** at the bottom of the product page. Check that the new software version is correct.



6. Select **Update**.

The progress of the software update is shown in percent under the product icon. When installation is completed, a check mark appears instead.



Troubleshooting guide

The below table provides information on some of the problems that might occur, including possible causes and remedies to solve the problems.

Problem	Possible cause	Remedy
The system cannot be switched on.	The SAILOR 6006 has a remote on/off switch, so the power button is disabled.	If the SAILOR 6006 is using a remote on/off switch, use that instead of the power button.
	There is no power on the input to the SAILOR 6006.	Check that all power cables between the ship power source and the SAILOR 6006 are connected correctly, and that the power source is on.
The Message Terminal cannot switch off.	Software error	Push and hold the Power button for 10 seconds, or reboot via the power cable.
There is no signal or weak signal from the satellite.	The view to the satellite is blocked, or there is a hardware problem.	<p>Make sure the SAILOR 3027 has a clear view in all directions. See the installation manual for details.</p> <p>If the view is not blocked, check the error log. If the problem persists, contact your local distributor.</p>
	The system is set up to use one specific satellite, but the system is outside coverage from that satellite.	Log into a satellite that covers your area.
No connection between SAILOR 6006 and SAILOR 3027	The CAN cables between the SAILOR 3027 and the SAILOR 6006 are damaged or are not properly connected.	Make sure the CAN cables are properly connected and that the cables and connectors are not damaged.

Problem	Possible cause	Remedy
No battery information in the SAILOR 6006	The Ethernet connection from the power supply is not working.	<p>Check the Link activity indicator at the connection points in the Ethernet switch.</p> <p>Check that the Ethernet cables are connected correctly and are not damaged.</p>
No connection between SAILOR 6006 and printer	The USB cable is damaged or is not connected properly.	Check that the USB cable is connected correctly and is not damaged.
The Message Terminal shows “out of paper” although there is paper in the printer.	The paper is not placed correctly in the printer.	Adjust the paper to the left side of the printer.
The units in the mini-C GMDSS do not appear in the TMA (Thrane Management Application).	The computer running the TMA is set up with a fixed IP address that does not match the local network with the mini-C GMDSS units.	<p>Enable DHCP on your computer.</p> <p>If you need to have a fixed IP address on your computer, there must be a DHCP server in the network, and the IP address of your computer must be within the range provided by the DHCP server.</p>

Status signalling

The SAILOR 6006 can show basic status and error messages. When an error occurs in the system, check the SAILOR 6006 for information first.

The SAILOR 1252 Printer also has some status LEDs. For further information see *Using the SAILOR 1252 Printer* on page 84.

Status information in SAILOR 6006

The upper right corner of the display shows the most important status information. You can also enter the individual pages from the main menu to see more detailed status information.

Information of events

Popup windows


When an event requires your attention, a popup window appears.

Example:



When you have read the text, select **OK** to close the window.

If the window indicates an error that requires your action, the warning or error icon will stay in the top right corner of the display as long as the problem persists.



List of active warnings and errors

The top right corner of the display shows a short text about the current status. The icon in the corner can change depending on the situation.




Green check mark: The system is logged in and there are no errors or warnings.



Warning triangle: A warning is pending. Select the icon or press F1 to see a list of active warnings and errors.



Red cross: A critical error is present. Select the icon or press F1 to see a list of active warnings and errors.



From the list of active warnings and errors you can access the event log.

Event log

From the list of active errors or warnings, you can select **Event log** to see a complete list of events. The list holds 100 events, including

- Errors
- Warnings
- Informational events
- Cleared warnings and errors.

Service and repair

Should your Thrane & Thrane product fail, please contact your dealer or installer, or the nearest Thrane & Thrane partner. You will find the partner details on [thrane.com](https://www.thrane.com) where you also find the Thrane & Thrane Self Service Center web-portal, which may help you solving the problem.

Your dealer, installer or Thrane & Thrane partner will assist you whether the need is user training, technical support, arranging on-site repair or sending the product for repair.

Your dealer, installer or Thrane & Thrane partner will also take care of any warranty issue.

Repacking for shipment

Should you need to send the product for repair, please read the below information before packing the product.

The shipping cartons for the SAILOR 6110 system have been carefully designed to protect the equipment during shipment. The cartons and their associated packing material should be used when repacking for shipment. Attach a tag indicating the type of service required, return address, model number and full serial number. Mark the carton “FRAGILE” to ensure careful handling.

Note

Correct shipment is the customer’s own responsibility.

GNU License texts

GNU General Public License

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA. Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.

b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.

c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program. In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,

c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE

PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to apply these terms to your new programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

Copyright (C)

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA.

Also add information on how to contact you by electronic and paper mail. If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author

Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w`.

This is free software, and you are welcome to redistribute it under certain conditions; type `show c` for details.

The hypothetical commands `show w` and `show c` should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w` and `show c`; they could even be mouse-clicks or menu items--whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program `Gnomovision' (which makes passes at compilers) written by James Hacker.

signature of Ty Coon, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Lesser General Public License instead of this License.

GNU Lesser General Public License

Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA. Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this

case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system. Although the Lesser General Public License is less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.
(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this

License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library. In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

- a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the

contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library. If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous

contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to apply these terms to your new libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

Copyright (C)

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

Appendix A: GNU License texts

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library `Frob' (a library for tweaking knobs) written by James Random Hacker.

signature of Ty Coon, 1 April 1990

Ty Coon, President of Vice

C

CAN Controller-Area Network. A message based protocol designed to allow microcontrollers and devices to communicate with each other within a vehicle without a host computer.

E

EGC Enhanced Group Call. A type of broadcast data for ships.

ENID EGC Network Identification. An identification code for a group of EGC receivers. When an EGC message is sent using the ENID, all members of a group with that ENID receive the same message.

G

GMDSS Global Maritime Distress Safety System. The GMDSS system is intended to perform the following functions: alerting (including position determination of the unit in distress), search and rescue coordination, locating (homing), maritime safety information broadcasts, general communications, and bridge-to-bridge communications.

GNSS Global Navigational Satellite System

GNU GNU's Not Unix. A Unix-like computer operating system developed by the GNU project, ultimately aiming to be a "complete Unix-compatible software system" composed wholly of free software

GPL General Public License

GPS Global Positioning System. A system of satellites, computers, and receivers that is able to determine the latitude and longitude of a receiver on Earth by calculating the time difference for signals from different satellites to reach the receiver.

GT Gross Ton

I

IMO International Maritime Organization. A UN organization developing and maintaining regulatory framework for shipping. This framework includes safety, environmental concerns, legal matters, technical cooperation, maritime security and the efficiency of shipping.

IMSO International Maritime Satellite Organisation. An intergovernmental body established to ensure that Inmarsat continues to meet its public service obligations.

L

LAN Local Area Network. A computer network covering a small physical area, like a home, office, school or airport. The defining characteristics of LANs, in contrast to wide-area networks (WANs), include their usually higher data-transfer rates, smaller geographic area, and lack of a need for leased telecommunication lines.

LES Land Earth Station

LGPL Lesser General Public License

M

METAREA The geographic areas in which various governments are responsible for meteorological warnings.

MRCC Maritime Rescue Coordination Centre

MSI Maritime Safety Information. Maritime Safety Information. An internationally coordinated network of broadcasts of Maritime Safety Information from official information providers, such as

National Hydrographic Offices, National Meteorological Offices, Rescue Coordination Centres (RCCs), and The International Ice Patrol, for Oceanic ice hazards.

N

NAVAREA The geographic areas in which various governments are responsible for navigation and weather warnings.

NCS Network Coordination Station

P

PSDN Public Switched Data Network

PSTN Public Switched Telephone Network. The network of the world's public circuit-switched telephone networks. It consists of telephone lines, fibre-optic cables, microwave transmission links, cellular networks, communications satellites, and undersea telephone cables all inter-connected by switching centres which allows any telephone in the world to communicate with any other.

S

SAC Short Access Code

SAR Search And Rescue

SARF Service Activation Registration Form. A form used to register your mobile equipment for activation of the services you are going to use.

SOLAS (International Convention for the) Safety Of Life At Sea. Generally regarded as the most important of all international treaties concerning the safety of merchant ships.

SSA Ship Security Alert. The ship security alert system is provided to a vessel for the purpose of transmitting a security alert to the shore (not to other vessel!) to indicate to a competent authority that the security of the ship is under threat or has been compromised.

T

TMA ThraneLINK Management Application. An application used to monitor and control products connected in a ThraneLINK network.

U

USB Universal Serial Bus. A specification to establish communication between devices and a host controller (usually personal computers). USB is intended to replace many varieties of serial and parallel ports. USB can connect computer peripherals such as mice, keyboards, digital cameras, printers, personal media players, flash drives, and external hard drives.

UTC Universal Time, Coordinated. The International Atomic Time (TAI) with leap seconds added at irregular intervals to compensate for the Earth's slowing rotation. Leap seconds are used to allow UTC to closely track UT1, which is mean solar time at the Royal Observatory, Greenwich.

A

- activation of service, 11
- adding contacts, 52
- alphabetic sorting of list, 26
- auto-print of EGCs, 69

B

- buttons
 - on SAILOR 1252 Printer, 86
 - on SAILOR 6006, 23

C

- characters, Cyrillic, 60
- clear protocol, 48
- configuration
 - duplicated system, 12
 - initial, 12
 - mini-C software or Radiotelex, 12
- Contacts, 50
 - adding, 52
 - editing, 54
- Cyrillic characters, 60

D

- data file
 - sending, 35
- data reporting, 73
- data reporting and polling
 - description of service, 10
- date and time format, 58
- deleting
 - EGC, 46
 - message, 46

- diagnostic report, 88

Distress

- buttons, testing, 81
- description of service, 7
- indications, clearing, 22
- message, writing, 28
- sending alert, 20
- settings, 63
- Distress LES number, 20, 65
- Distress position, 66
- DNIDs, 73
- document number
 - this manual, i
- duplicated system
 - configure, 13

E

- editing contacts, 54
- EGC
 - deleting, 46
 - description of service, 8
 - printing, 46
 - printing automatically, 69
 - receiving, 43
 - saving, 46
 - setup, 67
- encoding, Cyrillic characters, 60
- event log, 96

F

- file
 - sending, 35

G

GMDSS, 2
GNU General Public License, 99
GNU Lesser General Public License, 103

I

Inbox, 40
indicators in printer front panel, 85

L

LES number
 for Distress, 20, 65
link test, 48
lists, sorting, 26
login, 17, 48

M

manual
 document number, i
menu overview, 27
message
 deleting, 46
 Inbox, 40
 options, 39
 Outbox, 41
 printing, 46
 saving, 39, 46
 Sent items, 42
 writing, 33
messaging
 description of service, 9
mobile number
 entering, 71

N

NCS
 add, 76
 edit, 77
network
 logging into, 17
 login, 48
 scan, 48
 view status, 47
night mode, limits for, 58

O

Outbox, 41
overview of menus, 27

P

position
 for Distress, 66
 view current, 78
position information, 10
position reporting, 73
 description of service, 9
power status, 55
powering the system, 16
printer
 button functions, 86
 front panel indicators, 85
printing
 EGC, 46
 EGC automatically, 69
 message, 46
protocol, clearing, 48

R

receiving EGCs, 43
registration, 11
reporting position, 10, 73

S

safety summary, iv
SAILOR 1252 Printer
 button functions, 86
 front panel indicators, 85
saving
 EGC, 46
 message, 39, 46
scan, 48
send data file, 35
Sent items, 42
service activation, 11
services
 data reporting and polling, 10
 Distress, 7
 EGC, 8
 Inmarsat C details, 7
 messaging, 9
 position reporting, 9
software
 select mini-C or Radiotelex, 12
software update, 88
sorting a list, 26
special access codes, 53
SSA option, 5
starting up, 16
status
 network, 47
 power, 55
 signalling, 94
support, 87

system overview
 local, 1
 total, 3
system units, 4

T

ThraneLINK Management Application, 89
time and date format, 58
TMA, 89
 installing, 89
transmission, stop, 48
troubleshooting, 87
typography used in this manual, vii

U

units in the system, 4
update software, 88
user interface, 6
 navigating, 25

W

warranty, 97
writing messages, 33

98-130753-B