

## **Voyage Data Recorder**

Model VR-5000







The future today with FURUNO's electronics technology.

Catalogue No. N-849e

# Records essential navigational status, command an Helps locate casualty

- Complies with IMO A.861(20), IEC 61996, IEC 60945
- Reliable and fast data exchange between data collecting and data recording units via a single IEEE1394 cable
- Easy setup by using PC with Web Browser
- 12-hour recording of data with standard memory
- UTC time tagged for system synchronization and easy data retrieval
- Choice of flash memory capacity in the data recording unit
- Removable Hard Disk for backup of data stored in the Data Recording Unit

The VR-5000 is a Voyage Data Recorder (VDR) designed to meet IMO A.861 (20) and IEC 61996 regulations. The purpose of the VDR is to help investigators locate causes of marine casualty. In addition, the VDR can also be used to promote education for safe navigation.

The VR-5000 consists of a Data Collecting Unit (DCU), a Data Recording Unit (DRU), a Remote Alarm Panel (RAP) and six pieces of Microphones. The DCU contains interface modules, a powerful computer and a status monitor. It collects data from sensors as required by the IMO and IEC standards. The DCU processes the incoming data and information in the order of occurrence, while old data is overwritten with new data for storage in the DRU. The recording time is a minimum twelve hours with the standard flash memory. In case of an emergency power supply failure, the dedicated reserve batteries enable the VDR to record bridge audio for two hours.

The DCU is fitted with a removable hard disk for backup of data recorded in the DRU. The hot swap system and an external docking station for the removable hard disk allow data to be retrieved without interrupting the mandatory data collection.

The Data Recording Unit (DRU) stores the data coming from the DCU in the flash memory. All essential navigation and status data including bridge conversation, VHF communications and radar images are recorded. The data can be retrieved by using the playback software for educational briefing as well as accident investigation purposes. The DRU components are embodied in a protective capsule. The capsule ensures survival and recovery of the recorded data after an incident. An acoustic pinger helps locate the capsule.

#### Implementation schedule (International voyages)

-			
Type of ships		Schedule	
Passenger ships NB	1 July 2002		
Ro-ro passenger ships constructed before 1 July 2002		before first survey after 1 July 2002	9 1
Passenger ships other than ro-ro constructed before 1 July 2002			1 January 2004
NB other than passenger ships, of 3,000 gross tonnage+	1 July 2002		<b>47</b>



**Data Recording Unit** 

### nd control of ship. causes and promote education for safe navigation.

#### **Remote Alarm Panel**



The Remote Alarm Panel indicates status of system and gives audible and visual alarms. There are three buttons: SAVE, ACK (acknowledgement)

and TEST. Simply pressing the SAVE button allows you to save back up data recorded on the removable hard disk.



**Commercial PC** with playback software

#### FR-15X5 MK3 FAR-28x5 Series FAR-21x7/28x7 Series



**GPS Navigator GP-90** 



VHF R/T FM-8800S/D



Microphone 6 pieces standard



**Echo Sounder FE-700** 



**Doppler Speed Log DS-50** 

#### **Playback Data**

**Data** 



**Data Collecting Unit** 

#### Data to be recorded

- Date and time
- **Position**
- Speed
- Heading
- Bridge audio
- Communication audio (VHF)
- Radar images
- **Echo Sounder**
- Main alarms (IMO mandatory alarms)
- Rudder order and response
- **Engine order and response**
- Hull openings (doors) status
- Watertight and fire doors status
- Accelerations and hull stresses\*
- Wind speed and direction\*



\*Shall be recorded if available

#### **SPECIFICATIONS OF VR-5000**

#### **GENERAL**

#### **Rules and Regulations**

IMO A.861(20), IEC 61996, IEC 60945, IEC 61162

#### **Data Collecting Unit (DCU)**

Structure of DCU

Deck mounted, containing a status display, interface,

mainframe computer, dedicated reserve battery, power supply

for all VDR operation

Interface

Fire wire (IEEE1394) 1 ch

Serial interface IEC 61162: 8 channels Analog: 16 ports 12 ports Contact: Digital status (5-32 V): 52 ports Bridge communication: 2 ch (max 6 ch)

VHF audio: 2 ports Radar RGBHV (VGA to SXGA): 1 ch (max 4)

1 ch 10/100 Base-T Ethernet:

Integrity monitoring

Alarms for mains supply failure, recording function,

mic function

Data retrieval

Data stored in the CPU in the DCU may be copied for lesson or investigation with an optional software. Interruption of data storage to DRU is less than 8 minutes.

#### **Data Recording Unit (DRU)**

Memory

6 GB flash memory standard for IMO mandatory data for 12 h cycle, first-in first-out basis. Retains data for more than

10 years under no external power.

Larger memory for extended duty cycle (Optional)

#### **ENVIRONMENTAL TESTS** (for protective capsule)

1100°C for 1 h, 260°C for 10 h Fire:

(complies with ED 56A)

Shock: 50 G, duration 11 ms

Penetration: 250 kg with a pin ø100 mm dropped

from 3 m (ED 56A)

Deep sea immersion: 6,000 m

#### **Interconnection Diagram** GPS 8 ch (optional extra 8 ch) Speed log IEC 61162 Heading device (Gyro Compass, etc.) 12 ch Contact Closure Echo sounder IEEE1394 52 ch Digital Input Auto pilot Engine telegraph Steering gear M/E remote system Analog Main air comp RS-232C Bow thrusters 1 ch R/G/B/H/V (optional extra up to 3 ch) Shell door system Watertight doors Fire doors Anemomete 6 ch PC for system Fire detection Bridge Audio Main alarms system Radar 2 ch Microphone VHF VHF etc Option or 115/230 VAC 24 VDC Locally supply

Acoustic Pinger: Pinger emitting 10 ms pulses at

37.5 kHz. Automatically switched on

when submerged in water.

By playback equipment (not part of

standard VR-5000)

#### **POWER SUPPLY**

Data retrieval:

115 - 230 VAC, 50 - 60 Hz

#### **FOUIPMENT LIST**

#### Standard

1. Data Collecting Unit (incl. Removable Hard Disk) 1 unit

Data Recording Unit with 30 m cable and cradle


Microphone 6 sets Remote Alarm Panel 4 1 unit


5. Installation Materials and Spare Parts


#### Optional

Playback Software for displaying recorded data

- Docking station for Removable Hard Disk
- VHF Interface IF-5200







#### SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

**FURUNO U.S.A., INC.** Camas, Washington, U.S.A. Phone: +1 360-834-9300 Fax: +1 360-834-9400

**FURUNO (UK) LIMITED** Denmead, Hampshire, U.K. Phone: +44 2392-230303 Fax: +44 2392-230101 **FURUNO FRANCE S.A.** 

Bordeaux-Mérignac, France Phone: +33 5 56 13 48 00 Fax: +33 5 56 13 48 01

**FURUNO ESPAÑA S.A.** 

Madrid, Spain Phone: +34 91-725-90-88 Fax: +34 91-725-98-97

**FURUNO DANMARK AS** Hvidovre, Denmark Phone: +45 36 77 45 00 Fax: +45 36 77 45 01 **FURUNO NORGE A/S** 

Ålesund, Norway Phone: +47 70 102950 Fax: +47 70 127021

Espoo, Finland Phone: +358 9 4355 670 Fax: +358 9 4355 6710 FURUNO POLSKA Sp. Z o.o.

Västra Frölunda, Sweden Phone: +46 31-7098940 Fax: +46 31-497093 **FURUNO FINLAND OY** 

**FURUNO SVERIGE AB** 

Gdynia, Poland Phone: +48 58 669 02 20 Fax: +48 58 669 02 21

